


ST-c9128(M)C9128

1/4"(6MM) AIR DIE GRINDER



PARTS LIST

No.	Parts No.	Description	Q'ty
1	c9128-01	Collet Nut	1
2	c9128-02A	1/4" Collet	1
	c9128-02B	6mm Collet	1
3	c9128-03	Spindle	1
4	c9128-04	Coupling Nut	1
5	c9128-05	Lock Ring	1
6	c9128-06	Ball Bearing (608ZZ)	1
7	c9128-07	Frond End Plate	1
8	c9128-08	Bearing Spacer	1
9	c9128-09	Rotor	1
10	c9128-10	Rotor Blade	4
11	c9128-11	Cylinder	1
12	c9128-12	Spring Pin ($\Phi 2.5 \times 5$)	3
13	c9128-13	Rear End Plate	1
14	c9128-14	Ball Bearing (696ZZ)	1
15	c9128-15	Spring Pin ($\Phi 2.5 \times 20$)	1
16	c9128-16A	Valve Screw -Plastic	1

No.	Parts No.	Description	Q'ty
16	c9128-16B	Valve Screw -Brass (Option)	1
17	c9128-17	O-Ring (P10A)	1
18	c9128-18	Valve Spring	1
19	c9128-19	Throttle Valve	1
20	c9128-20	O-Ring (P4)	1
21	c9128-21	Valve Shaft ($\Phi 3.9 \times 24$)	1
22	c9128-22	Safety Lever Ass'y	1
23	c9128-23	Spring Pin ($\Phi 3 \times 22$)	1
24	c9128-24	O-Ring (S22.4)	1
25	c9128-25	Inlet Bushing	1
26	c9128-26	Housing Cover	1
27	c9128-27	Spanner Wrench Set (#19)	1
28	c9128-28	Aluminum Spacer	1
29	c9128-29	Spanner Wrench Set (#14)	1
30	c9128-30	Motor Housing	1
31	c9128-31	Exhaust Sleeve	1