




**MAINTENANCE INSTRUCTIONS
SECTION D'ENTRETIEN
WARTUNG
SEZIONE DI MANUTENZIONE
INSTRUCCIONES DE MANTENIMIENTO
ONDERHOUD**



(TPA1367)



PART NUMBER FOR ORDERING
REFERENCE POUR COMMANDE DE LA PIECE
BESTELNUMMER
NUMERO DEL PEZZO PER L'ORDINAZIONE
SIMBOLO DE LA PIEZA PARA PEDIDOS
BESTELNUMMERS

| | | | | | |
|----|---------------------|----|---------------------|----|---------------------------|
| 1 | LA421-DG-40001 | 20 | LA421-VP-70013 | 36 | LA421-DG-40051 |
| 2 | LA421-DG-40002 | 21 | LA421-BB-62012 | 37 | LA421-DG-40052 |
| 3 | LA421-BB-06262 | 22 | LA421-DG-40029 | 38 | LA421-AR-38001 |
| 4 | LA421-DG-40004 | 23 | LA421-DG-40030 | 39 | LA421-DG-40054 |
| 5 | LA421-BB-62022 | 24 | LA421-DG-40039 | 40 | LA421-DG-40055 |
| 6 | LA421-WK-0313A | 25 | LA421-T2-3008B (2) | 41 | LA421-DG-40056 |
| 7 | LA421-DG-40007 | 26 | LA421-PG-38043 | 42 | LA421-ORP-0120 |
| 8 | LA421-WW-0010 | 27 | LA421-ORP-0040 | 43 | LA421-ORP-0050 |
| 9 | LA421-STW-010 | 28 | LA421-AG-30052 (4") | 44 | LA421-DG-40059 |
| 10 | LA421-DG-40010 | 28 | LA422-AG-30052 (5") | 45 | LA421-DG-40061 |
| 11 | LA421-DG-40011 | 29 | LA421-AG-30053 (4") | 46 | LA421-DG-40062 |
| 12 | LA421-DG-40012 (4") | 29 | LA422-AG-30053 (5") | 47 | LA421-SP-30175 |
| 12 | LA422-DG-40012 (5") | 30 | LA421-AG-40059 (4") | 48 | LA421-SP-40300 |
| 13 | LA421-SW2-050A (5) | 30 | LA422-AG-40059 (5") | 49 | LA421-DG-40065 |
| 14 | LA421-B2-0512A (5) | 31 | LA421-AG-30054 (4") | 50 | LA421-DG-40066 |
| 15 | LA421-DG-40015 | 31 | LA422-AG-30054 (5") | 51 | LA421-301 (4") (LA421-EU) |
| 16 | LA421-DG-40016 | 32 | LA421-AP-70047 | 51 | LA422-301 (5") (LA422-EU) |
| 17 | LA421-VP-70017 | 33 | LA421-DG-40048 | 52 | 107-304 |
| 18 | LA421-SP-30060 | 34 | LA421-AG-30058 | 53 | EU-99 |
| 19 | LA421-VP-70014 (4) | 35 | LA421-BB-06082 (2) | | |